



## Lawren Cardigan

Style# W1411 / Women's French Terry Cardigan

MEASUREMENT (in inches)	XS	S	M	L	XL	XXL
Chest Diameter (1" below armhole)	15 ½	16 ½	17 ½	18 ½	20	21 ½
Sleeve Length (From C.B. To Cuff)	30	31	32	33	33 ¾	34 ½
Body Length (From H.P.S.)	24	25	26	27	27 ½	28

**IMPORTANT:**

To ensure accuracy, please follow the measuring instructions in the diagram below.

**CHEST:**

Measure 1" under the arms, across the fullest part of the chest, laid flat from seam to seam.

**SLEEVE LENGTH:**

With sleeves relaxed at side, measure from center back neck (C.B.), over the shoulder, down to the end of cuff.

**BODY LENGTH:**

From the highest point of shoulder (H.P.S.), measure the length of the garment.

